






## Medical Consumables Tracking (MCT)













## HRP Gap that MCT Addresses



# Gap 4.14 - We do not have the capability to track medical inventory in a manor that integrates securely with the medical system during exploration missions



#### MCT Goals



#### **Technical ISS Demonstration Testing Goals**

- Demonstrate that the system correctly identifies that an item has been removed
- Transmit data to the SSC via ISS JSL
- Verify functionality in the electrically noisy ISS

#### **Advantages**

- 1. Scheduled crew time not required to inventory medications/medical consumables; supplying more time for other activities
- 2. Know when medical supplies are low
- 3. Actual usage data can be used to resupply the kits
- 4. Actual usage data used for exploration mission planning



## Concept of Operations (on-orbit)




#### Glenn Research Center

- RFID tags are attached to the contents of the Convenience Medications Pack (pharmaceuticals), and foam ear plugs, which are kept in a CHeCS RSR (Resource Supply Rack) locker
- MCT Hardware installed inside the CHeCS RSR locker and on the outside of the locker door
- The crew will access medications and consumables as before (no procedural changes)
- MCT system will turn on and read (perform inventory) RFID tagged items in the locker once every 30 days
- The inventory report (RFID tag numbers only) is transmitted wirelessly to the Joint Station LAN then downlinked to the HMS Inventory Tracking Tool (HITT) database that has tag id to item id cross-reference info
- The crew can perform an inventory via a switch located on the Electronic Box



## MCT Technology









#### What will MCT track?



#### CHeCS RSR Locker D2



- The MCT System is currently tasked to track the Convenience Medications Pack and Ear Plugs
- The above items were selected for tracking because they are items most frequently used by the crew
- Tagging individual items or dose levels for pills
- 503 items = 503 RFID tags




#### MCT Hardware Overview



#### The MCT Hardware consists of:

- Embedded Computer System
- RFID Near-field Antennas (2)
- RFID Reader/Writer
- Inventory Control and Power Converter Assembly
- RFID Tags




## RFID Tags



#### RFID Tags

- Consist of a RFID chip and small antenna
- Tag antenna is energized from the system reader and antenna
- Chip is activated and transmits its Electronic Product Code (EPC) Value back to the reader
- At present, the MCT system is tasked to read ~400 tags, but may increase depending on future Med Kit packing densities








## Hardware Installed on the Door



9

A thermal gasket will heat sink the electronics box to the panel that attaches to the locker door.



Profile with locker door closed (top down view)



## RFID Tag Installation



#### Objectives when tagging items:

- MCT team will provide instructions as to the tag type, optimum orientation, and position of the RFID tag on each medical item
- RFID tags placed on packaging must not interfere with ease of opening
- RFID tags must not obscure labeling of unit dose
- Addition of RFID tags must add minimal bulk to existing item packages
- Where possible place the RFID tag on the item itself, if not then RFID tag will be placed on re-closable bag.



## RFID Tagging Plan



- RFID tags will be pre-programmed with EPC code
- The EPC value will have the letter 'M' programmed in the most significant byte location followed by 'MCT'. This signifies that the RFID tag is attached to a Medical Consumables item
- MCT will provide programmed RFID tags on a roll
- RFID tag will be removed from roll and placed on Ziploc bag or directly on item (where possible)
- Medication label will be placed on top of RFID tags located on the Ziploc bag
  - The addition of the Medication label improves separation between the RFID tags, providing improved reading capability
  - Provides protection for the RFID tag



### System Inventory



- Inventory schedule once every 30 days
- Inventory takes less than 5 minutes
- Crew have the ability to initiate an inventory cycle manually
- Crew can access medications at any time
- If during a crew access MCT initiates an inventory period or during an inventory period there is crew access, MCT will automatically terminate the inventory period and start another period once no access activity is detected
- Inventory is only performed when the locker door is closed
- LED indicator on the Electronic Box will illuminate when an inventory cycle is being performed
- All items detected are recorded and sent to the JSL server



## MCT Tags



Two different UHF RFID tags, each using the Impinj Monza 5 RFID chip, were selected for testing.


<u>Invengo Scorpion XCTF-8039-C13-FPI</u>: This inlay is optimized for small and medium distances, which is suitable for pharmacy, clothing or assets tracking applications.

<u>LAB-ID SKL4020-MZ5</u> This inlay is used in apparel tracking or item level tracking applications.

An image of each RFID inlay is shown below




**SKL4020-MZ5** 



Scorpion (XCTF-8039-C13-FPI)

<sup>\*</sup>Images are not to scale



## MCT Testing



The MCT RSR CHeCS (*Crew Health Care System*) enclosure is an aluminum chassis with an approximate volume of 3.6 ft<sup>3</sup>. The enclosure will perform as a Faraday cage and restrain the transmitted RF from interfering with external equipment. This enclosure can contain 6 medical packs each measuring  $\approx 16.4$ " x 14.5" x 4". Each pack can contain as many as 350 densely packed RFID tags. Tagged materials are in the form of metals, liquids, plastic, paper, and tablet medications (packaged and blister packs).

The two custom Applied EM antennas are attached to the left and right side walls of the chassis. The ThingMagic RFID reader/writer is located on the top (outside the environment).



MCT RSR CHeCS Locker Simulator



Antennas Mounted Left Wall



Antennas Mounted to Right Wall



## MCT Testing (cont'd)



The Convenience Medications Pack contains the non-contingency medication for afflictions deemed to be frequent and which require oral, injectable, or topical administration. The Convenience Medications Pack Assembly is packaged in a 16" x 14" x 4" blue Nomex bag. A nylon zipper wraps around 3 sides of the bag on the 4" wall to allowing it to open and lay flat. Most of the sub-assemblies are contained inside small zipper lock bags with a hook fastener attached to secure to the inside of the bag.



The MCT Convenience Medications Pack contains either the exact same type medical item or in the case of oral medications a placebo.